




1. Diagram / 示意图



Front-View / 正-视图





Top-View / 顶-视图



Left side-View / 左侧-视图





1. CPU cooler installation:
Please ensure that your CPU cooler does NOT exceed 6.4 inch (162 mm) in height, it will cause damage to the side panel of the case and the CPU cooler.
2. Please ensure that your graphics card does NOT exceed 12.4 inch (315 mm) in length, it will cause damage to the case and the graphics card.



2. Installation Guide / 安装说明



2.1

- EN** How to remove the side panel
AR الجانبى اللوح إزالة كيفية
BG Как се отстранява страничният панел
CHS 拆下侧板
CHT 拆下侧板
CS Jak odstranit postranní kryt
DE So entfernen Sie die Seitenplatte
EL Πως να αφαιρέσετε τον πλευρό πλάκα
ES Cómo quitar el panel lateral
FR Comment retirer le panneau latéral
HU Oldalsó panel eltávolítása
IT Come rimuovere il pannello laterale
JP サイドパネルの取り外し方
KR 사이드 패널 제거 방법
KZ Бүйір тақтаны қалай алу керек
NL Verwijderen van het zijpaneel
PL Jak zdjąć pokrywę boczną
PT Como remover o painel lateral
RU Как снять боковую панель
SR Kako da uklonite bočnu ploču
TR Yan paneli kaldırma





2.2

- EN** How to install the power supply
AR الطاقة موثر تثبيت كيفية
BG Как се поставя захранващата връзка
CHS 安装电源
CHT 安裝電源
CS Jak instalovat zdroj napájení
DE So installieren Sie das Netzteil
EL Πως να εγκαταστήσετε τη τροφοδοσία
ES Cómo instalar la fuente de alimentación
FR Comment installer l'unité d'alimentation
HU Tápellátás bekötése
IT Come installare l'alimentatore
JP 電源の取り付け方
KR 파워 서플라이 설치 방법
KZ Қуат көзі блогын қалай орнату керек
NL Installeren van de voeding
PL Jak podłączyć zasilacz
PT Como instalar a fonte de alimentação
RU Как установить блок питания
SR Kako da instalirate napajanje
TR Güç kaynağını kurma





2.3

- EN** How to install the motherboard
AR الأم اللوحة تثبيت كيفية
BG Как се инсталира дънната платка
CHS 安装主板
CHT 安裝主機板
CS Jak nainstalovat motherboard
DE So installieren Sie das Motherboard
EL Πως να εγκαταστήσετε τη Μητρική μονάδα
ES Cómo instalar la placa base
FR Comment installer la carte mère
HU Alaplap összeszerelése
IT Come installare la motherboard
JP マザーボードの取り付け方
KR 마더보드 설치 방법
KZ Аналық платаны қалай орнату керек
NL Installeren van het moederbord
PL Jak zamontować płytę główną
PT Como instalar a placa-mãe
RU Как установить материнскую плату
SR Kako da instalirate matičnu ploču
TR Anakartı kurma



2.4



- EN** How to install the add-on cards
AR مضافة بطاقات تثبيت كيفية
BG Как се инсталират допълнителните платини
CHS 安装显卡
CHT 安裝顯示卡
CS Jak nainstalovat přídatné karty
DE So installieren Sie Erweiterungskarten
EL Πως να εγκαταστήσετε τις κάρτες προσθήκης
ES Cómo instalar tarjetas adicionales
FR Comment installer les cartes supplémentaires
HU Add-on kártyák beszerelése
IT Come installare le schede aggiuntive
JP アドオンカードの取り付け方
KR 애드 온 카드 설치 방법
KZ Кеңейту карталарын қалай орнату керек
NL Installeren van de uitbreidings kaarten
PL Jak podłączyć karty rozszerzeń
PT Como instalar as placas adicionais
RU Как установить карты расширения
SR Kako da instalirate dodatne kartice
TR Eklenli kartlarını kurma



2.5



- EN** How to install the 5.25" and 3.5" devices
- AR** بوصة 5.25" و 3.5" مقياس الأجهزة تثبيت كيفية
- BG** Как се инсталират 5,25" и 3,5" устройствата
- CHS** 安装光驱和3.5" 硬盘
- CHT** 安裝光碟機和3.5" 硬碟
- CS** Jak nainstalovat zařízení 5.25" a 3.5"
- DE** So installieren Sie 5,25"- und 3,5"-Geräte
- EL** Πως να εγκαταστήσετε τις κάρτες προσθήκης
- ES** Cómo instalar tarjetas adicionales
- FR** Comment installer les cartes supplémentaires
- HU** 5.25" és 3.5" eszközök beszerelése
- IT** Come installare le unità da 5.25" e da 3.5"
- JA** 5.25インチ及び3.5インチデバイスの取り付け方
- KR** 5.25", 3.5" 장치를 설치하는 방법
- KZ** 5,25"/3.5" құрылғысын қалай орнату керек?
- NL** Installeren van de 5.25" en 3.5" apparaten
- PL** Jak zamontować urządzenia 5.25" i 3.5"
- PT** Como instalar os dispositivos 5,25 e 3,5 pol
- RU** Как установить устройства 5,25" и 3,5"
- SR** Kako da instalirate 5,25" i 3,5" uređaje
- TR** 5,25" ve 3,5" aygıtları kurma


2.5.1 Remove the front bezel




2.5.2 Install 5.25" device

※ Secure by 5.25" Tool-free







✱ Secure by screw



2.5.3 Install 3.5" device into external bay



2.6

EN How to install the hard disk drive

AR بوصة مقاس الصلب القرص تثبيت كيفية

BG Как се инсталира твърдият диск

CHS 安装硬盘

CHT 安裝硬碟

CS Jak nainstalovat pevný disk

DE So installieren Sie die Festplatte

EL Πως να εγκαταστήσετε τη μονάδα σκληρού δίσκου

ES Cómo instalar la unidad de disco duro

FR Comment installer le lecteur du disque dur

HU Merevlemez-meghajtó beszerelése

IT Come installare il disco rigido

JP ハードディスク・ドライブの取り付け方

KR 인치 하드 디스크 드라이브 설치 방법

KZ қатқыл дискіні қалай орнату керек

NL Installeren van de harde schijf

PL Jak zamontować dysk twardy


PT Como instalar o drive do disco rígido

RU Как установить накопитель на жестком диске


SR Kako da instalirate čvrsti disk

TR Sabit disk sürücüsünü kurma


2.6.1 Install 3.5" device




* Secure by 3.5" tool-free



* Secure by screw





2.6.2 Install 2.5" HDD / SSD




- EN** How to install or replace case fans
- AR** الكمبيوتر حافظة مروحة استبدال أو تثبيت كيفية
- BG** Как се инсталират или заменят вентилаторите на кутията
- CHS** 安装和更换机箱风扇
- CHT** 安裝和更換機箱風扇
- CS** Jak nainstalovat či vyměnit větráky
- DE** So installieren Sie Gehäuselüfter oder tauschen sie aus
- EL** Πως να εγκαταστήσετε ή να αντικαταστήσετε τους ανεμιστήρες του περιβλήματος
- ES** Cómo instalar o reemplazar los ventiladores de la carcasa
- FR** Comment installer ou remplacer les ventilateurs du boîtier
- HU** Ventilátorok szerelése vagy cseréje
- IT** Come installare o sostituire le ventole del case
- JP** ケース・ファンの取り付けと交換方法
- KR** 케이스 팬 설치 또는 제거하는 방법
- KZ** Қаңқалық желдеткіштерді қалай орнату керек
- NL** Installeren of vervangen van de case fans
- PL** Jak zamontować lub wymienić wentylatory w obudowie
- PT** Como instalar ou substituir ventoinhas da caixa
- RU** Как установить или заменить корпусные вентиляторы
- SR** Kako da instalirate ventilatore u kućište i da ih menjate
- TR** Kasa fanlarını kurma veya değiştirme


2.7.1 Install front fan (1 x 120mm)



2.7.2 Install rear fan (1 x 120mm)





2.7.3 Install side fan (1 x 120mm)



2.8

- EN** Completing installation
AR التثبيت استكمال
BG Завършване на инсталацията
CHS 完成安裝
CHT 完成安裝
CS Dokončení instalace
DE Abschließen der Installation
EL Ολοκλήρωση εγκατάστασης
ES Completar la instalación
FR Terminer l'installation
HU Telepítés elvégzése

- IT** Completamente dell'installazione
JP 組み込み完了
KR 설치 완료하기
KZ Орнатууды аяқтау
NL Installatie voltooid
PL Kończenie instalacji
PT Finalizar a instalação
RU Завершение установки
SR Dovršavanje instalacije
TR Kurulum tamamlanıyor



I/O Function panel installation guide

- Please refer to the illustrations in the motherboard user manual that describe USB 3.0, USB 2.0, and audio connector support. The motherboard connectors must match the included front panel cables in this case. Attempting to install anything other than matching connectors may result in damage and loss of function.
- On some motherboards, the connectors for USB 3.0, USB 2.0 and Audio are not the same as the drawing below. Please check with your motherboard manual before installing.
- The following illustration is a diagram showing the I/O connectors.

Motherboard	Case Connector
USB 3.0 connector 	USB 3.0 connector
USB 2.0 connector 	USB 2.0 connector
AC'97 	AC'97 Connector
Azalia (Intel High Definition Audio) 	HD Connector

I/O面板安裝說明

- 请参考主板使用说明书的USB 3.0、USB 2.0、声音插孔章节的图示。另外，请选用以下标准USB 3.0、USB 2.0、音效连接头，避免损坏本产品。
- 一些主机板的 USB 3.0、USB 2.0、音效连接头与下图不符，安装前，请参阅主板使用说明。
- 下图为I/O电缆的连接线图。

主机板	线材
USB 3.0 接口	USB 3.0 接口
USB 2.0 接口	USB 2.0 接口
AC'97	AC'97 接口
Azalia (Intel 高音质接口)	HD 接口